


## Phase I




Niveau 1 -





Niveau 2 à 14 -



4 ½ 5 ½


\*Les balcons varient selon les étages, se fier aux plans de vente



## Phase II



Niveau 1 -




206 à 406 1) pe 44 (4-1/2) 1) pe 30 (3-1/2) 1) pe 30 (3-1/2)

Niveau 2 à 4



Niveau 15 –



4 ½ 5 ½

Niveau 5 à 14

## 80 **5**a

## Phase III



222 et 322
TYPE 4E (41/2)
948 PI

224 et 324
TYPE 50 (51/2)
1314 PI<sup>2</sup>

226 et 326
TYPE 4D (41/2)
1057 PI

230 et 330
TYPE 4F (41/2)
988 PI<sup>2</sup>

230 et 330
TYPE 4F (41/2)
988 PI<sup>2</sup>


772 PI<sup>2</sup>

772 PI<sup>2</sup>

3 ½ 4 ½ 5 ½

Niveau 1 -

Niveau 2 et 3







Niveau 4 à 14

Niveau 15 –